

RDB130001 SPARE PART LIST

Exploded view No.	Part name	qty	Exploded view No.	Part name	qty
1	Clip ring	1	27	screwST4.2×12	1
2	Stop collar	1	28	cover of oil box	1
3	Fastening sleeve	1	29	pillar wool felt $\phi 8 \times 10$	2
4	Spring	1	30	oil box	1
5	Steel ball $\phi 7.938$	6	31	O ring $\phi 51 \times \phi 2$	1
6	screw M8X30	4	32	crankshaft	1
7	Iron head	1	33	D47 clip ring	1
8	O ring $\phi 44 \times \phi 2$	1	34	O ring $\phi 46 \times \phi 2$	1
9	impact shaft	1	35	bearing 6303	1
10	impact shaft washer	1	36	gearbox	1
11	rectangle shock pad	1	37	distance sleeve	1
12	O ring $\phi 38 \times \phi 2$	2	38	oil seal	1
13	head of cylinder	1	39	flat key	2
14	O ring $\phi 26.3 \times \phi 4.3$	2	40	crankshaft gear	1
15	cylinder case	1	41	Seal ring	1
16	screwM8×35	4	42	bearing 6001	1
17	cylinder	1	43	middle cover	1
18	washer $\phi 38.2 \times \phi 46 \times 2$	1	44	O ring $\phi 35 \times \phi 1.8$	1
19	rectangle circle	1	45	bearing 6202	1
20	cylinder limit pad	1	46	D15 clip ring	1
21	strike hammer	1	47	rotor	1
22	O ring $\phi 28.4 \times \phi 3.5$	2	48	clip ring	1
23	piston pin	1	49	bearing 608	1
24	piston	1	50	screw ST4.2×80	2
25	connection rod	1	51	fan guide	1
26	oil bearing	1	52	stator	1

RDB130001 SPARE PART LIST

Exploded view No.	Part name	qty	Exploded view No.	Part name	qty
53	housing of motor	1	65	Capacitance	1
54	screw M6×55	4	66	switch	1
55	brush holder	2	67	trigger	1
56	screw ST2.9×12	8	68	right handle	1
57	carbon brush	2	69	screw M6×22	2
58	disc spring	2	70	damping seat	1
59	rear cover of motor	1	71	damping cap	1
60	screw KA40×16	9	72	damping spring	1
61	Cable and plug	1	73	auxiliary handle grip	1
62	cable protector	1	74	handle holder	1
63	left handle	1	75	brace	1
64	cable clamp	1	76	band	1

